

## Description

# DASH CONTROL VALVE WITH TWO STEP FUNCTION FOR PARK RELEASE

### CROSS REFERENCE TO RELATED APPLICATIONS

[0001] This application is a continuation-in-part of pending U.S. Application No. 09/852,232, filed May 8, 2001.

### BACKGROUND OF INVENTION

[0002] The invention relates to the art of vehicle braking systems and finds particular application in heavy trucks, tractors, and buses. The invention will be described in relation to an air pressure braking system of a tractor-trailer truck system. It will be appreciated, however, that the invention is also amenable to other applications (e.g., other braking systems such as those of other kinds of vehicles and those based on other technologies such as hydraulic or electronic braking systems).

[0003] U.S. Patent No. 4,844,553 to Bliss and U.S. Patent No. 4,330,157, which are both incorporated herein by reference, disclose control valve arrangements for use in a

braking system. The valve arrangements include a pair of valve actuators or plungers that are operated by a vehicle operator. One of the actuators controls communication between an air pressure source and a tractor parking/emergency brake system. The tractor parking/emergency brake system includes spring brakes that are actuated to resist wheel rotation. A force of an included spring or set of springs in the spring brakes urges a braking member against the wheel. During vehicle operation, air pressure is applied against a piston that is associated with the springs. The force applied against the piston counteracts the force of the springs thereby releasing the spring brake and allowing the wheels of the vehicle to rotate. The other actuator controls communication between the pressure source and service brakes of a trailer.

[0004] In addition to providing for manual application and release of the parking/emergency brakes, the disclosed valve arrangements also provide for the automatic application of brakes should the source or actuation pressure fall below a threshold. That is to say, the first actuator is forced into a pressure exhaust position by internal springs if the source pressure drops below a first threshold. Similarly the other actuator is forced into a pressure exhaust

position if the pressure drops below a second threshold. This provides for the trailer brakes and the tractor brakes to be applied in an appropriate order should a malfunction or leak occur in the braking system.

[0005] One feature the prior art valve arrangements do not provide is an assurance that a vehicle operator has actuated the service brakes before the parking brakes are released. As a result, the vehicle could roll unexpectedly when the operator releases the parking brakes.

[0006] Therefore, a braking system interlock arrangement that requires the service brakes of a vehicle to be engaged before the parking brakes of the vehicle can be disengaged is desired.

[0007] The present invention provides a new and improved apparatus and method which addresses the above-referenced problems.

## **SUMMARY OF INVENTION**

[0008] In one embodiment, a valve assembly for an air pressure system includes an inlet valve, a first control valve, and a second control valve. The inlet valve includes an inlet port, an outlet port and a control port. The inlet valve inlet port communicates with the inlet valve outlet port when the inlet valve control port is above a threshold pressure. The

first control valve includes an inlet port, an outlet port, an exhaust port, and a control member. The first control valve inlet port communicates with the inlet valve outlet port. The first control valve outlet port communicates with one of the first control valve inlet port and the first control valve exhaust port as a function of a position of the first control valve control member. The second control valve includes an inlet port, an outlet port, an exhaust port, and a control member. The second control valve inlet port communicates with the inlet valve outlet port. The second control valve outlet port communicates with one of the second control valve inlet port and the second control valve exhaust port as a function of a position of the second control valve control member.

#### **BRIEF DESCRIPTION OF DRAWINGS**

[0009] In the accompanying drawings which are incorporated in and constitute a part of the specification, embodiments of the invention are illustrated, which, together with a general description of the invention given above, and the detailed description given below, serve to exemplify the embodiments of this invention.

[0010] *FIGURE 1* is a schematic diagram illustrating the control logic of a braking system control block operative to re-

quire a two-step brake release process.

[0011] *FIGURES 2A and 2B* are a diagram showing a first valve assembly configured as a braking system control block operative to require a two-step brake release process, the valve assembly being in a first operational state.

[0012] *FIGURES 3A and 3B* are a diagram showing the valve assembly of *FIGURES 2A and 2B* in a second operational state.

[0013] *FIGURES 4A and 4B* are a diagram showing the valve assembly of *FIGURES 2A and 2B* in a third operational state.

[0014] *FIGURES 5A and 5B* are a diagram showing the valve assembly of *FIGURES 2A and 2B* in a fourth operational state.

[0015] *FIGURES 6A and 6B* are a diagram showing the valve assembly of *FIGURES 2A and 2B* in a fifth operational state.

[0016] *FIGURE 7* is a functional diagram of an inlet valve shown in a first operational state.

[0017] *FIGURE 8* is a functional diagram of the inlet valve of *FIGURE 7* in a second operational state.

[0018] *FIGURE 9* is a functional diagram of a third valve assembly configured as a braking system control block operative to require a two-step brake release process.

## **DETAILED DESCRIPTION**

[0019] Referring to *FIGURE 1*, a valve assembly 104 operative to require an operator of a vehicle to apply service brakes

106 of the vehicle before both i) tractor parking or spring brakes 107 and ii) trailer parking or spring brakes 184 can be released includes a control double check valve 108 and an inlet valve 110. The inlet valve 110 and control double check valve 108 co-operate to form a sensor, system inlet valve, and an interlock device. As will be seen below, the sensor monitors the state of the vehicle braking system. The system inlet valve directs pressure to certain parts of the braking system at appropriate times as determined by the sensor. The interlock latches the sensor and system inlet valve into a permissive or open state when appropriate.

[0020] More particularly, the control double check valve 108 includes a service pressure port 114, a locking pressure port 116, and a control pressure outlet 118. The control double check valve 108 operates to direct system status information to the sensor. For example, the information is in the form of system pressures. The control double check valve 108 directs a greater of pressures applied at the service pressure port 114 and the locking pressure port 116 to the control pressure outlet 118.

[0021] The inlet valve 110 includes an actuating pressure port 120, an input or supply pressure input port 122, and an

output or supply pressure delivery port *124*. Additionally the valve includes a biasing member *126* for urging the inlet valve toward a closed position, thereby blocking air flow to the supply pressure delivery port *124* from the supply pressure input port *122*. The actuating pressure port *120* communicates with the control pressure outlet *118* of the control double check valve *108* through a control check valve output channel *130*. When air pressure delivered to the actuating pressure port *120* exceeds that required to counteract the urging force of the biasing member *126*, the inlet valve is actuated to permit flow and pressure equalization between the input port *122* and delivery port *124*.

[0022] The input port *122* communicates with a supply pressure source through a supply selector double check valve *131* and a supply conduit *132*. The supply conduit *132* connects to the check valve *131* at a selected supply delivery port *134*. The supply selector double check valve *131* includes a primary supply port *136* connected to a primary supply reservoir *140* via a primary supply line *142* and a secondary supply port *138* connected to a secondary supply reservoir *144* via a secondary supply line *146*. The supply selector double check valve *131* directs a higher of

pressures from the primary supply port and the secondary supply port to the selected supply delivery port *134*.

[0023] Typically, the pressurized air is delivered to the supply reservoirs *140* , *144* by one or more pumps or compressors (not shown). The pressurized air is used to actuate various components of the vehicle braking system. For example, the pressurized air is used to drive a piston and counteract the force of the springs thereby releasing the brake pads from engagement with respective wheels (not shown) in the tractor and trailer spring brakes *107* , *184*.

[0024] The control double check valve *108* and the inlet valve *110* work together to provide pressurized air for enabling release of the tractor parking brakes *107* and the trailer parking brakes *184* at appropriate times. When it is inappropriate to release the parking brakes the control double check valve *108* and the inlet valve *110* work together to prevent the delivery of pressurized air to the spring brakes *107*, *184*.

[0025] For example, port *114* of the control double check valve *108* communicates with a service brake line *152* to receive pressurized air from a service supply double check valve *153*. The check valve *153* directs, for example, a higher of two pressures delivered from a proportional valve *154* to



the service brake line. Here, the proportional valve 154 is operatively associated with a brake pedal (not shown) of the vehicle. The proportional valve 154 receives pressurized air from a primary service supply conduit 155 and a secondary service supply conduit 156. The proportional valve 154 proportions the pressures delivered to it. For example, the proportional valve 154 delivers a proportioned primary supply pressure and a proportioned secondary supply pressure to the service supply double check valve 153. The proportioned pressures depend on the degree of actuation of the proportional valve 154. For example, if the brake pedal is not actuated at all, then the delivery pressure of the proportional valve 154 is 0 psi. If the brake pedal is partially depressed then a percentage or fraction of the primary and secondary supply pressures are delivered to service supply double check valve 153. Obviously, various pressures or fractional pressures may be delivered as well. The service supply double check valve 153 then directs one of the supplied pressures to the service brake line 152 to effect braking. When the pressure in the service brake line 152 is higher than a pressure at the locking pressure port 116 the control double check valve operates to deliver the service brake line pressure to

the actuating pressure port *120* of the inlet valve *110*, thereby indicating that degree to which the service brakes are applied to the wheels of the vehicle. When the pressure at the actuating pressure port *120* exceeds a predetermined threshold, for example 25 psi, the inlet valve *110* directs supply pressure from the supply conduit *132*, to the supply delivery port *124* where it enables the tractor and trailer spring brakes *107*, *184*, respectively, to be released once the respective plungers are deactuated as will become more apparent below.

[0026] For example, the supply delivery port *124* is connected to a parking/emergency brake control valve *160* and a trailer parking/emergency brake control valve *180* via a first control valve supply conduit *162*.

[0027] The spring brake control valve *160* includes a tractor spring brake supply port *164*, a tractor spring brake exhaust port *166*, and a tractor spring brake delivery port *168*. The spring brake delivery port *168* communicates with the tractor spring brake system *107* via a spring brake pressure line *170*. Additionally, the spring brake pressure line *170* provides spring brake pressure to the locking pressure port *116* of the control check valve. A biasing spring *172* urges the tractor spring brake control

valve toward an exhaust state, wherein any pressure stored in the spring brakes *107* is normally vented via the tractor spring brake exhaust port *166*.

[0028] It is anticipated that in a comparable electrical braking system, energy will not be stored in the braking system. Therefore, in an electrical analog to the exhaust state, the parking brakes would simply be de-powered. However, some designs, such as, for example capacitive and inductive designs may benefit from energy regeneration or dissipation. Therefore in an electrical analog to the exhaust state, the parking brakes may be connected to an energy storage device or a dummy load.

[0029] The trailer air supply valve *180* includes a trailer air supply port *181*, a trailer air exhaust port *182*, and a trailer air delivery port *183*. The delivery port *183* is connected to the trailer air system *184* via a trailer air line *185*. A biasing member or spring *186* urges the trailer air supply valve *180* to an exhaust state position where pressure in the trailer air system *184* is vented to atmosphere *178*. In order to supply air to the trailer systems *184*, the operator must deactuate (e.g., push) a plunger button *187* associated with the trailer air supply valve *180*. Deactuating the plunger directs whatever pressurized air that is present at

the trailer air supply port *181* to the trailer air delivery port *183*. Additionally, pressurized air at the trailer air delivery port *183* is applied to a trailer air supply valve pilot or control port *188*. Pressure at the pilot port *188* holds the trailer air supply valve plunger (not shown) and button *187* in position after the operator releases the plunger button *187*, thereby holding the trailer air supply valve *180* in the trailer system pressurization state. The trailer air supply valve *180* directs pressurized air for releasing brakes of a trailer. Additionally, trailer air pressure is made available to power trailer accessories such as conveyer belts, ramps and lifts. In one embodiment, pressurized air from the trailer air supply valve is delivered to the trailer system through a tractor protection valve. The tractor protection valve serves to isolate the tractor systems from the trailer in the event of an unintentional disconnection.

[0030] As described above, in order to release the tractor parking or spring brakes *107* or the trailer parking or spring brakes *184*, the operator must first apply the service brakes. Additionally, the operator must also deactuate plunger buttons or control switches *174* , *187* associated with the tractor spring brake control valve *160* and the trailer air supply valve *180*, respectively. Deactuating the

plunger buttons 174, 187 positions the control valve 160 in a tractor spring brake pressurization state and the trailer air supply valve 180 in a trailer spring brake pressurization state.

[0031] While in the tractor spring brake pressurization state, the tractor control valve 160 directs pressurized air at the supply port 164 to the delivery port 168. Additionally, pressurized air at the spring brake delivery port 168 is applied to a tractor spring brake control valve pilot or control port 176. Pressurized air at the pilot port 176 latches or holds the tractor spring brake control valve in position after the operator releases the plunger button 174, thereby latching the tractor spring brake control valve 160 in the spring brake pressurization state. Furthermore, system status information, in the form of spring brake pressure, delivered to the locking pressure port 116 of the control double check valve 108 is directed to the actuation port 120 of the inlet valve 110, thereby locking or latching the inlet valve in a supply pressure delivery state in response to the secondary or spring brakes being in a released state. The control double check valve 108 also operates to isolate the service brake line 152 from the spring brake system.

[0032] While in the trailer spring brake pressurization state, the control valve 1 8 0 directs pressurized air at the supply port 1 81 to the delivery port 1 83. Additionally, pressurized air at the spring brake delivery port 183 is applied to a trailer spring brake control valve pilot or control port 1 88. Supply pressure at the pilot port 1 88 latches or holds the trailer spring brake control valve in position after the operator releases the plunger button 1 87, thereby latching the trailer spring brake control valve 1 8 0 in the spring brake pressurization state.

[0033] When the operator desires to again park the vehicle and apply the tractor parking/spring brakes 107 and/or the trailer parking/spring brakes 1 84, the operator actuates the plunger buttons 174, 187 to overcome forces associated with the spring brake pressure applied to the tractor spring brake control valve pilot port 176 and the spring brake pressure applied to the trailer brake control valve pilot port 188. This returns the tractor and trailer spring brake control valves 160 , 180 to their exhaust states. Pressures at the tractor and trailer spring brake delivery ports 168 , 183 are vented to exhaust ports 166 , 182 and the spring brakes engage the wheels of the vehicle tractor and trailer. Additionally, pressure at the locking pressure port

116 is relieved. Therefore, pressure is relieved from the actuating pressure port 120 of the inlet valve 110. The spring 126 then urges the inlet valve into a closed position, thereby preventing the release of the tractor parking brakes 107 and the trailer parking brakes 184 without a prior application of the service brakes 106.

[0034] When the tractor and trailer spring brake control valves 160, 180 are placed in an exhaust state in order to vent or relieve pressure in the tractor and trailer spring brakes 107, 184, pressurized air flows from the tractor spring brake exhaust port 166 and the trailer spring brake exhaust port 182 to atmosphere 178. An exhaust conduit 190 carries the exhaust flow from the tractor spring brake exhaust port 166 to atmosphere 178.

[0035] Having described the invention in general terms, details of an exemplary embodiment are now discussed. Referring to *FIGURES 2A and 2B*, a valve assembly 604 requires an operator of a vehicle to apply service brakes 606 of the vehicle before parking spring brakes 607 of the vehicle tractor and parking spring brakes 609 of the vehicle trailer are released. The valve assembly comprises a control double check valve 608 and an inlet valve 610. The control double check valve 608 and inlet valve 610 reside in a common

housing 612. The housing 612 includes a check valve chamber 614 and an inlet valve chamber 616.

[0036] The control double check valve 608 includes a spacer 618, a biasing spring 620, and check valve member 622. The spacer includes grooves 624 that carry seals such as o-rings 626. The seals 626 divide the check valve chamber 614 into a first region 628 and a second region 630. The spacer 618 includes a passage 632 that provides communication between the first region 628 and the second region 630. Additionally, the spacer includes a first valve seat 634 operative to receive the check valve member 622. As will be further described in reference to *FIGURES 3A and 3B*, a second region end 636 of the passage 632 is closed when the first valve seat 634 receives the check valve member 622.

[0037] The spring 620 is located between the spacer 618 and the check valve member 622, urging the check valve member 622 toward a second valve seat 638. When seated on the second valve seat 638, the check valve member 622 isolates the second region 630 from a service pressure port 640.

[0038] The inlet valve 610 includes a valve frame 642, a piston 644, a piston spring 646, a valve guide 648, an inlet valve



member 650, and an inlet valve member return spring 652. The valve frame 642 includes a set of grooves 654 carrying associated seals 656 that divide the inlet valve chamber 616 into a third region 660, fourth region 661, and fifth region 662. The valve frame 642 also includes a piston guide region 664 and an inlet valve seat 666. The inlet valve seat 666 is located at a boundary between the fourth 661 and fifth 662 regions of the inlet valve chamber.

[0039] During inlet valve 610 operation, the inlet valve member is occasionally seated on the inlet valve seat 666. During those times, the inlet valve member 650 and the inlet valve seat 666 form a seal separating the fourth 661 and fifth 662 inlet valve regions. When the inlet valve member 650 is not seated on the inlet valve seat 666, there is free communication between the fourth 661 and fifth regions 662. As will be explained in greater detail below, the valve frame 642 also includes various grooves, cutouts and passages that, either alone, or in cooperation with various inlet valve components, form passages or conduits for air flow.

[0040] The piston 644 has a piston head 668 and a shaft portion 669. The piston head 668 and the shaft 669 each include grooves carrying seals 670 to maintain isolation between

the third and fourth inlet valve regions 660, 661. The shaft 669 is slidably received in the piston guide region 664 of the frame 642. The piston is urged toward the third region 660 by piston spring 646. The piston spring 646 is mounted between an overhang portion of the piston head 668 and a piston spring support 674 portion of the inlet valve frame 642. The piston shaft 669 includes a valve guide bore 676. The valve guide bore 676 is located axially with respect to the piston shaft 669.

[0041] The valve guide 648 is, for example, a pin. The valve guide 648 is received within the valve guide bore 676. A portion of the valve guide 648 projects outwardly from the valve guide bore into the fifth region 662 of the inlet valve chamber 616.

[0042] In one embodiment, the inlet valve member 650 is made of a resilient material such as rubber. The inlet valve 650 member includes a valve guide bore 677 axially located with respect to the inlet valve member 650. The guide bore 677 receives a tip of the projecting portion of the valve guide 648 to axially locate the inlet valve member 650 within the fifth region 662 of the inlet valve chamber 616.

[0043] The second region 630 of the control double check valve

608 communicates with the third region 660 of the inlet valve 610 through a second passage 679. In addition to the control double check valve 608 and the inlet valve 610, the first embodiment 604 further comprises a primary pressurized air source 680, a secondary pressurized air source 681, a source selection valve 682, a service brake actuator or pedal 683, a tractor spring brake control valve 684, and a trailer air supply valve 685.

[0044] The primary and secondary pressure sources 680, 681, respectively, are each connected to the source selection valve 682 which directs air from one of the pressure sources to an inlet port 686 of the inlet valve 610 through a supply conduit 687. The primary and secondary pressure sources are also each connected to the service brake actuator 683 through first and second service supply lines 689, 690, respectively.

[0045] The service brake actuator 683 delivers proportioned pressure outputs to a second source selection valve 691 through first 689' and second 690' respective service actuator output lines. The pressures delivered in output lines 689', 690' are related to both their respective supplies 680, 681 and the position of the service brake actuator 683. The second source selection valve 691 connects one of the

output lines 689', 690' to a service brake line 692 based on the relative pressures of the airs contained within the output lines 689', 690'. For example, the output line containing air at a higher pressure is directed to the service brake line 692.

[0046] The service brake line delivers the selected output pressure to the service brakes 606 of the vehicle. Additionally a branch of the service brake line delivers the selected output pressure to a control inlet 693 of the control double check valve 608. When the check valve member is not seated on the second valve seat 638, the control inlet 693 communicates with the second region 630 of the control double check valve 608.

[0047] An inlet valve outlet port 694 is connected to a tractor spring brake valve inlet port 695 of the tractor spring brake control valve 684 and a trailer valve inlet 688 of the trailer air supply valve 685 through an inlet valve output conduit 696. The inlet valve outlet port 694 communicates with the fourth region 661 of the inlet valve 610.

[0048] A tractor valve delivery port 697 is connected to a spring brake line 698. A branch of the spring brake line 698 is connected to a lockout port 699 of the control double check valve. The lockout port 699 communicates with the

first region 628 of the control double check valve 608.

[0049] As depicted in *FIGURES 2A and 2B*, the first embodiment 604 of a valve assembly is in a brake release prevention state. Supply pressure is available in the supply conduit 687. Additionally, plunger buttons of the tractor spring brake control valve 684 and the trailer air supply valve 685 have been deactuated. Therefore, the tractor spring brake control valve 684 and the trailer air supply valve 685 are configured to deliver air to the tractor spring brakes 607 and the trailer spring brakes 609 for causing the spring brakes to release the wheels (not shown). However, the service brake actuator 683 has not been actuated and, therefore, no pressure is applied to the control input 693 of the control double check valve and no pressure is applied to the piston 644 to counteract the force of the spring 646.

Therefore, the piston is positioned toward the third region 660 and the inlet valve member 650 is seated on the inlet valve seat 666.

[0050] Although supply pressure is available at the inlet valve inlet 686 and therefore in the fifth region, there is no communication between the fifth and fourth regions. Therefore, supply pressure is not available at the inlet valve outlet port 694 and no supply pressure is available at the

tractor spring brake valve inlet 695 or the trailer valve inlet 688. Deprived of supply pressure, neither the tractor spring brake control valve 684 nor the trailer spring brake control valve 685 can deliver pressurized air to the spring brake line even though the valve is configured to do so. Therefore, the tractor spring brakes remain engaged and the vehicle is prevented from rolling unexpectedly.

[0051] Referring to *FIGURES 3A and 3B*, the valve assembly 704 illustrates a second operational state of the *FIGURES 2A and 2B* embodiment. In the second operational state, a tractor spring brake control valve 708 and a trailer spring brake control valve 707 are in respective spring brake exhaust configurations. A tractor valve button 710 and associated plunger 712 is actuated (lifted upwardly as shown), thereby directing pressurized air in spring brake line 714 connected at a spring brake delivery port 716 to an exhaust port (not shown). The tractor spring brakes 718 thus engage the wheels of a vehicle, thereby preventing the vehicle from rolling. Similarly, a trailer valve button 711 and associated plunger 713 is actuated (lifted upwardly as shown), thereby directing pressurized air in spring brake line 715 connected at a spring brake delivery port to an exhaust port (not shown). The trailer spring brakes 709

thus engage the wheels of the vehicle, thereby preventing the vehicle from rolling.

[0052] Additionally, in the second operational state, service brake actuator/brake pedal 720 is actuated so that air in service brake line 722 is above a threshold pressure and the service brakes 724 engage the wheels (not shown) of the vehicle. The threshold pressure is selected so that the vehicle will not roll unexpectedly if the tractor spring brakes or the trailer spring brakes 718 , 709, respectively, are released. Service pressure is also delivered to an input 726 of a control double check valve 728. With the check valve member 730 unseated from valve seat 734, the pressurized air at the control input 726 communicates with the second check valve region 742 and with a passage 744 between the second check valve region 742 and a third region 746 of an inlet valve 748. A force arising from pressure applied to the piston overcomes a force of a piston spring 752 so that the piston moves toward a fourth region 754 of the inlet valve. Valve guide 756 moves with the piston 750 and an inlet valve member 757 associated with the valve guide. Both the valve guide 756 and inlet valve member 757 are moved further into a fifth region 758 that communicates with an inlet valve supply port 759. The fourth region 754

communicates with an inlet valve outlet port 760. As a result of movement of the inlet valve member from an inlet valve seat 762, a communication path is opened between the fourth and fifth inlet valve regions. Pressurized air delivered to the inlet valve inlet port 759 is communicated to the fourth region 754 by the communication path that was opened when the inlet valve member 757 was lifted off the inlet valve seat 762. As described above, the inlet valve outlet port 760 communicates with the fourth region 754. Therefore, the inlet valve outlet port 760 also receives pressurized air which is made available to a tractor spring brake control valve inlet port 770 and a trailer spring brake control valve inlet port through an inlet valve output conduit 771. If the tractor valve button 710 (and associated plunger 712) or the trailer valve button 711 (and associated plunger 713) were deactuated (e.g., pushed down), the tractor spring brake control valve 708 and the trailer spring brake control valve would deliver pressurized air for releasing the spring brakes 718 , 709, respectively.

[0053] Referring to *FIGURES 4A and 4B*, the valve assembly (now referenced as numeral 804) is shown in a third operational state. In the third operational state, the service brake pedal 808 has been actuated beyond a threshold degree so



that supply pressure is available at a tractor valve inlet port 810 of a tractor spring brake control valve 812. However, in the third state, tractor valve button 814 and a tractor valve plunger 816 are deactuated while trailer valve button 811 and a trailer valve plunger 813 are actuated. As is explained in greater detail in the U.S. Patent 4,844,553 to Bliss, previously incorporated by reference, depressing the valve button 814 and plunger 816 directs pressurized air available at the inlet port 810 to a tractor spring brake control valve delivery port 818 and to tractor spring brakes 820 through a spring brake line 822, thereby releasing the tractor spring brakes. Since the trailer valve button 811 and plunger 813 are actuated, the trailer spring brakes 809 are engaged. A branch of the spring brake line also delivers pressurized air to a lockout port 824 of a control double check valve 826. The lockout port 824 communicates with a first region 828 of the control double check valve 826. A passage 829 in spacer 830 conducts pressurized air in the first region 828 to a second region 834 of the passage 828, urging check valve member 836 away from a first check valve seat 838 and against a second check valve seat 840.

[0054] The pressurized air in the passage 829 acting downwardly

(relative to the FIGURE) on the check valve member 836 is higher than or equal to a pressure of pressurized air acting upwardly (relative to the FIGURE) on the check valve member 836 and, therefore, the check valve member is pressed against the second seating surface 840 thereby sealing off the control input. The check valve member 836 is moved away from the first seating surface and pressurized air flows through the passage into a third region 842 of the control double check valve and into a second passage 848 that communicates with a fourth region 850 of an inlet valve 852. This provides a force acting on piston 856 of the inlet valve 852 and, in this way, spring brake line pressure 822 delivered to the lockout port 824 latches the inlet valve 852 in an open position independent of the degree of actuation of the service brake actuator 808. This allows the tractor spring brakes to be maintained in their released state after a vehicle operator, for example, removes his foot from a service brake pedal 808.

[0055] Referring to *FIGURES 5A and 5B*, the valve assembly 904 is in a fourth operational state. The fourth operational state is similar to the third operational state of *FIGURES 4A and 4B*; however, the service brake pedal 908 is not actuated. Nevertheless, pressure in spring brake line 910 is delivered to

a lockout port 912 and serves to hold an inlet valve 914 in an open position. Therefore supply pressure continues to be delivered to a tractor spring brake control valve inlet 916 of a tractor spring brake control valve 918 and a trailer spring brake control valve inlet 942 of a trailer spring brake control valve 940. A plunger 920 (and button 922) of the tractor spring brake control valve 918 and a plunger 913 (and button 911) of the trailer spring brake control valve 940 are maintained in a deactuated (depressed) position (relative to the FIGURE). For example, internal to the tractor spring brake control valve 918 the pressure of the air applied to the inlet 916 overcomes the force generated by a tractor valve return spring 924 and holds the plunger 920 in the depressed position. Therefore, supply pressure continues to be delivered to the spring brake line 910, spring brakes 926 and the lockout port 912. Additionally, supply pressure at the inlet 916 is also delivered to an inlet 942 of the trailer supply valve inlet 942. The pressure at the inlet 942 holds a plunger 944 of the trailer supply valve 940 in the depressed position. The trailer supply valve 940 delivers supply pressure to trailer systems, including, for example, trailer spring brakes (not shown). In one embodiment, a tractor protection valve 946 is included between

the trailer supply valve 940 and the trailer. With pressure supplied to the trailer, parking brakes of the trailer are released and the combination vehicle (tractor and trailer) can be driven to its destination.

[0056] Referring to *FIGURES 6A and 6B*, the valve assembly is shown in a fifth operational state which is actually a transition from the fourth operational state to the first operational state. In the fifth operational state plunger buttons 1006, 1008 and plungers 1010, 1012 of the tractor spring brake control valve 1014 and a trailer supply valve 1016 have been actuated (i.e., lifted). Therefore the valves 1014, 1016 are in an exhaust position where pressurized air from spring brakes 1018 and spring brake line 1020 is vented through a tractor spring brake control valve exhaust port 1022. Likewise, pressurized air from a trailer system (not shown) and trailer supply line 1024 is vented through a trailer supply valve exhaust port 1026.

[0057] Additionally, in the fifth operational state, a service brake actuator 1028 is not actuated so that air pressure in service brake line 1030 is zero. For example, the pressure of air in the service brake line is below a threshold thereby indicating that the service brakes are not engaged sufficiently to prevent the vehicle from rolling unexpectedly.

As the spring brakes *1018* and spring brake line *1020* are vented, pressurized air in a first region *1032* of a control double check valve *1034* flows from a lockout port *1036* of the control double check valve *1034* and into the spring brake line *1020* to be vented to atmosphere. As air leaves the first region *1032*, air in a second region *1038* of the control double check valve *1034* flows through a first passage *1040* into the first region *1032* and out the lockout port *1036*. Therefore, a pressure in the second region *1038* is reduced. Similarly, air in a third region *1042* of an inlet valve assembly *1044* flows through a second passage *1046* into the second region *1038* and eventually out the lockout port *1036*. As pressurized air leaves the third region *1042*, a piston spring or resilient member *1048* is able to urge a piston *1050* of the inlet valve assembly *1044* toward the third region *1042*. As the piston *1050* moves toward the third region *1042*, forces from an inlet valve member return spring *1052* and/or pressurized air supplied from an inlet port *1054* of the inlet valve assembly *1044* urge an inlet valve member *1056* and an associated valve *1058* guide toward and further into a fourth region *1060* of the inlet valve assembly *1044*, respectively. Ultimately, the inlet valve member *1056* is seated on an inlet valve seat *1062*

thereby preventing communication between the fifth region 1064 and the fourth region 1060. Therefore, no significant amount of pressurized air is available to the tractor spring brake valve inlet port 1070 or the trailer spring brake valve inlet port. When substantially all the pressurized air has been vented or returned to a low pressure tank or reservoir, the transition is complete and the fifth valve assembly 1004 is in the first operational state.

[0058] Referring to *FIGURE 7*, a closed inlet valve assembly 1304 preferably includes a venting means 1308 operative to vent air from a fourth region 1312 of the closed inlet valve assembly 1304. A piston 1314 is positioned in a right-most piston position so that a third region 1316 of the inlet valve assembly 1304 is at a minimum size. An inlet valve member return spring 1320 urges an inlet valve member 1322 and a valve guide 1324 into a right-most position. The inlet valve member 1322 is seated on valve seat 1330. Therefore, communication between a fifth region 1334 and the fourth region 1312 of the inlet valve assembly 1304 is prevented. Typically, the inlet valve assembly 1304 assumes the closed state when an operator of a vehicle switches the tractor spring brake control valve 160, 684, 1216 from a spring brake release state into a spring brake

exhaust state. This operation tends to trap pressurized air in the fourth region *1312* of the inlet valve assembly *1304* and in an inlet valve output conduit or passage *162*, *696* (see *FIGURES 1, 2A, and 2B*).

[0059] This trapped air can affect the operation, sound and feel of the tractor spring brake control valve when the operator next attempts to release the spring brakes. For example, as the tractor spring brake control valve is moved from the exhaust state to the spring brake release state, trapped air would flow from the fourth region *1312* and associated passages into the spring brake line. As the air is delivered, an audible sound is emitted even if the primary and secondary pressure reservoirs are empty. In this case, the sound may confuse the operator into believing the spring brakes are released, when, in fact, they are still engaged. Additionally, the trapped air resists the operator's actuation of the tractor spring brake control valve. For example, the operator must compress the trapped air in order to move the tractor spring brake control valve into the spring brake release state. For the forgoing reasons, the inlet valve assembly *1304* preferably includes the venting means *1308*.

[0060] For example, the venting means includes a vent seat *1340*.

The vent seat 1340 is operative to receive the inlet valve member 1322 when the inlet valve is in an open state. However, in the illustrated closed state, the inlet valve member 1322 is not seated on the vent seat 1340. When the piston 1314 is in the illustrated right-most position, the inlet valve seat 1330 serves to separate the inlet valve member 1322 from the vent seat 1340. The vent seat 1340 is at an inlet valve member end of an axial bore 1342 in a shaft portion 1344 of the piston 1314. The bore 1342 is operative to slidably receive the valve guide 1324. Additionally, a gap 1346 between the valve guide 1324 and a wall 1348 of the bore is operative as a first portion of a piston vent passage 1350 in the piston 1314. When the inlet valve assembly 1304 is in the illustrated closed state, the vent seat 1340 is positioned in the fourth region 1312. The piston vent passage 1350 is in communication with a frame vent passage 1352. The frame vent passage 1352 communicates with a vent region 1353, e.g., atmosphere.

[0061] When the inlet valve member 1322 is not seated on the vent seat, as shown in *FIGURE 7*, the fourth region 1312 is in communication with the piston vent passage 1342 through the open vent seat 1340, the piston vent passage 1350, and in turn with the frame vent passage 1354 and



the vent region 1353. When the inlet valve assembly 1304 is in the closed state, the venting means 1308 is in an open state. Therefore, air that would otherwise be trapped in the fourth region 1312 and associated passages when the inlet valve is closed is instead vented. Of course, the venting means 1308 must be sealed or closed when the inlet valve assembly 1304 is in an opened state.

[0062] Referring to *FIGURE 8*, an open inlet valve assembly 1404 includes a sealed venting means 1408. A piston 1414 is positioned so that a third region 1416 of the inlet valve assembly 1404 is at a maximum size. Inlet valve member 1422 is unseated from inlet valve seat 1430 to form a communication path 1432 between fourth region 1436 and fifth region 1434. Typically, the inlet valve assembly 1404 is urged toward an open state when an operator of a vehicle actuates a service brake actuator 154, 683 in preparation to release parking spring brakes of a vehicle. This delivers pressurized air to the third region 1416 of the inlet valve assembly 1404 and drives the piston 1414 to the illustrated left-most position. As a result, the inlet valve member is urged against a vent seat 1444 portion of the piston 1414. Additionally, pressurized air in the fifth region 1434 also urges the inlet valve member against the vent seat 1444.

Therefore, pressurized air is prevented from leaking out through the venting means *1408* while the inlet valve assembly *1404* is in the open state.

[0063] Referring to *FIGURE 9*, the inlet valve assembly *1304*, *1404* of *FIGURES 7 and 8* may be included in any of the valve assembly embodiments described herein. The third valve assembly *1504* includes in a single housing *1508*, a tractor spring brake control valve *1510*, a trailer supply valve *1512*, a supply selector *1514*, a control double check valve *1516*, and an inlet valve *1518*.

[0064] As described previously, the supply selector *1514* communicates with primary and secondary supply input ports *1521*, *1522*. Typically the primary and secondary supply ports are connected to primary and secondary pressurized air reservoirs (not shown). A selector check valve member *1524* of the supply selector *1514* moves to direct one of the primary and secondary supplies to a supply passage *1525*. For example, the supply delivering pressurized air at the highest pressure is directed to the supply passage *1525*.

[0065] The supply passage *1525* delivers pressurized air to an inlet or fifth region *1526* of the inlet valve *1518*.

[0066] The control double check valve *1516* communicates with a control input port *1530*, a control check valve output pas-

sage 1531 and a lockout passage 1532. As previously described, in a first mode of operation, a control check valve member 1533 within the control double check valve 1516 moves to direct one of pressurized air delivered to the control input port 1530 and pressurized air delivered to the lockout passage 1532 to the control check valve output passage 1531. For example, the port 1530 or passage 1532 carrying pressurized air at the highest pressure is directed to the control check valve output passage 1531. In a second mode of operation, pressurized air in the control check valve output passage 1531 is vented through the lockout passage 1532. The control check valve output passage 1531 merges into a third, or actuation region or piston, or control port 1534 of the inlet valve 1518. The lockout passage 1532 is in communication with a seventh region 1536 of the tractor spring brake control valve 1510.

[0067] The tractor and trailer spring brake control valves 1510, 1512, respectively, communicate with other devices through tractor and trailer valve input ports 1538, 1528, respectively, a spring brake delivery port 1540, and a first exhaust passage 1542. The tractor and trailer valve input ports 1538, 1528 receive pressurized air from a fourth inlet valve region 1544 through an inlet valve output passage

1546. Of course, the tractor and trailer valve input ports 1538 , 1528 only receive pressurized air when the inlet valve 1518 is open. Of course, as previously described in reference to other figures, the inlet valve 1518 is only open when pressurized air directed to the third region or piston port 1534 by the control double check valve 1516 from the control port 1530 or the lockout passage 1532 are of sufficient pressure to hold the inlet valve 1518 open.

[0068] When the tractor spring brake control valve 1510 is pulled upward (actuated) (relative to the figure) into an exhaust state, as depicted in *FIGURE 9*, any pressurized air delivered to the tractor valve input port 1538 will pressurize a tractor valve plunger passage 1548. However, the pressurized air from the tractor valve input port 1538 can travel no further, since distal ends 1550 of the plunger passage 1548 are isolated by plunger seals 1551 from any other region or passage. Additionally, when the tractor spring brake control valve 1510 is in the illustrated exhaust state, air in the lockout passage 1532 and the spring brake delivery port 1540 are placed in communication with, and flow out through, the first exhaust passage 1542 through an eighth region 1552 of the tractor spring brake control valve 1510.

[0069] When the tractor spring brake control valve 1510 is pushed downward (deactuated) (relative to the figure) into a delivery state, the distal ends 1550 of the plunger passage are placed in communication with the seventh region 1536 of the tractor spring brake control valve 1510. Therefore, pressurized air delivered to the tractor valve input port 1538 is placed in communication with the lockout passage 1532 and with the spring brake delivery port 1540. Pressurized air in the seventh region 1536 works on a tractor valve seal 1556. The pressurized air provides a force that overcomes a spring force of a tractor valve spring 1554. Therefore, when the tractor spring brake control valve 1510 is placed in the delivery state and the seventh region is filled with pressurized air, the pressurized air serves to hold or latch the tractor spring brake control valve 1510 in the delivery state. In the depressed position (not shown), or deliver state, the tractor valve seal 1556 is seated on a tractor valve seat 1557. In this position the tractor valve seal 1556 prevents communication between the first exhaust passage 1542 and the seventh 1536 or eighth 1552 tractor valve regions.

[0070] The trailer supply valve 1512 operates in a similar manner. The trailer supply valve 1512 communicates with other de-

vices through the trailer valve input port 1528, a trailer delivery port 1562, a reset passage 1564 or sampling point and, through the reset passage with an exhaust port 1565. As mentioned above, the trailer valve input port 1528 receives pressurized air from the inlet valve output passage 1546.

[0071] When the trailer supply valve 1512 is pulled upward (actuated) (relative to the figure), into an exhaust state, as depicted in *FIGURE 9*, any pressurized air delivered to the trailer valve input port 1528 pressurizes a trailer valve plunger passage 1566. However, the pressurized air from the trailer valve input port 1560 can travel no further since distal ends 1567 of the plunger passage 1566 are isolated by plunger seals 1568 from any other region or passage. Additionally, when the trailer supply 1512 is in the illustrated exhaust state, air in the trailer delivery port 1562 passes through a tenth region 1570 of the trailer supply valve 1512, through the trailer supply valve reset passage 1564 and is vented or exhausted through the exhaust port 1565.

[0072] When the trailer supply valve 1512 is pushed downward (relative to the figure) into a delivery state, the distal ends 1567 of the plunger passage 1566 are placed in communi-

cation with a ninth region 1572 of the trailer supply valve 1512. Therefore, pressurized air delivered to the trailer valve input port 1528 is placed in communication with the trailer delivery port 1562. Pressurized air in the ninth region 1572 works on trailer valve seal 1576, providing a force that overcomes a spring force of a trailer valve spring 1575. Therefore the trailer supply valve 1512 is held or latched in a depressed or delivery state. In the delivery state (not shown) a trailer valve seal 1576 is seated on a trailer valve seat 1577. In this position the trailer valve seal 1576 prevents communication between the trailer supply valve reset passage 1564 and the ninth 1572 or tenth 1570 tractor valve regions.

[0073] Of course, pressurized air delivered to the trailer delivery port 1562 flows out of the valve assembly. Typically the trailer system (not shown) is connected to the trailer delivery port 1562. Therefore, when the trailer valve plunger is in the depressed position, pressurized air flows from the supply selector 1514, through the inlet valve 1518, the inlet valve output passage 1546, and the trailer plunger passage 1566 into the ninth region 1572, out the trailer delivery port 1562 and into the trailer system.

[0074] Of course, at low system pressures, the force working on

the trailer valve seal 1576 falls below a threshold and the trailer valve spring forces the trailer supply valve 1512 into the exhaust state, thereby applying the brakes of any attached trailer.

[0075] In addition to the low pressure auto exhaust feature just described, the trailer supply valve 1512 can also be automatically driven into the exhaust state by exhaust air from the tractor spring brake control valve 1510. When the tractor spring brake control valve 1510 is switched or moved into the exhaust state, pressurized air from a spring brake line (not shown) attached to the spring brake delivery port 1540 is directed to the first exhaust passage 1542 through the tractor spring brake control valve 1510. As the air flows toward the exhaust port 1565, reset port 1564 is also pressurized. If the trailer supply valve 1512 is in the delivery state when tractor spring brake control valve 1510 exhaust air pressurizes the reset port, then a force generated by the pressure in the reset port is added to a force delivered by the trailer valve spring 1575. The combined forces overcome the force generated by pressurized air in the tenth region 1570 applied to the trailer valve seal 1576. Therefore, the trailer supply valve 1512 is automatically switched into the exhaust state.



[0076] While the present invention has been illustrated by the description of embodiments thereof, and while the embodiments have been described in considerable detail, it is not the intention of the applicants to restrict or in any way limit the scope of the appended claims to such detail. Additional advantages and modifications will readily appear to those skilled in the art. Therefore, the invention, in its broader aspects, is not limited to the specific details, the representative apparatus, and illustrative examples shown and described. Accordingly, departures may be made from such details without departing from the spirit or scope of the applicant's general inventive concept.